



# **StarMOBILE™**

## Software Installation Guide

**A complete reference for installing and updating your  
StarMOBILE™ software**



**INTRODUCTION.....3**

**INSTALLING THE STARMOBILE DESKTOP CLIENT.....3**

    INSTALLING WITH THE *STARSCAN & STARMOBILE UPDATE CD*..... 3

*Step 1: Before You Begin*..... 3

*Step 2: Insert the StarSCAN & StarMOBILE Update CD* ..... 4

*Step 3: Follow the StarMOBILE Desktop Client Setup Wizard*..... 4

*Step 4: Launch the StarMOBILE Desktop Client*..... 5

    UPDATING SOFTWARE VIA DEALERCONNECT ..... 5

**UPDATING THE STARMOBILE DEVICE OS.....6**

    UPDATING AUTOMATICALLY USING THE *STARMOBILE DESKTOP CLIENT*..... 6

*Step 1: Launch the StarMOBILE Desktop Client*..... 6

*Step 2: Follow the StarMOBILE Discovery Wizard* ..... 6

*Step 3: Follow the StarMOBILE Update Wizard*..... 7

    UPDATE MANUALLY USING THE *STARSCAN & STARMOBILE UPDATE CD*..... 7

## Introduction

This guide outlines the steps required to:

- Initially install or update your StarMOBILE Desktop Client software on your PC
- Update your StarMOBILE device's operating system

If you have problems installing your StarMOBILE software, refer to the StarMOBILE Software Installation Troubleshooting Guide located at [dealerconnect.chrysler.com](http://dealerconnect.chrysler.com) by navigating to DealerCONNECT > Service > Repair > StarSCAN and StarMOBILE Tools. This document is also available from the *Download Center* at [www.dcctools.com](http://www.dcctools.com).

## Installing the StarMOBILE Desktop Client

### Installing with the *StarSCAN & StarMOBILE Update CD*

#### *Step 1: Before You Begin*

Make sure your PC meets or exceeds the following requirements:

- Windows 2000 SP4 or later
- Pentium 166 MHz or later
- 32MB RAM
- 100MB of hard drive space available

Locate the latest *StarSCAN & StarMOBILE Update CD*. This update CD is sent when software updates become available for the StarSCAN and StarMOBILE devices.

Information on the latest StarSCAN and StarMOBILE software releases can be found in the *Latest News* section of the DealerCONNECT website located at [dealerconnect.chrysler.com](http://dealerconnect.chrysler.com) by navigating to DealerCONNECT > Service > Repair > StarSCAN and StarMOBILE Tools. This information is also available in the *Latest News* section at [www.dcctools.com](http://www.dcctools.com).

Note: Your StarMOBILE kit may have shipped with a *StarMOBILE Installation CD* which has now been deprecated. Always use the latest *StarSCAN & StarMOBILE Update CD* to update your StarMOBILE Desktop Client, as it contains the latest software updates.


## *Step 2: Insert the StarSCAN & StarMOBILE Update CD*

Insert the *StarSCAN & StarMOBILE Update CD* and choose *Install Desktop Client*. This will launch the StarMOBILE Desktop Client InstallShield Wizard.



## *Step 3: Follow the StarMOBILE Desktop Client Setup Wizard*

Follow the InstallShield wizard to install the StarMOBILE Desktop Client software.



## Step 4: Launch the StarMOBILE Desktop Client


An icon will appear on the desktop upon successful installation. Double click the icon to verify that the StarMOBILE Desktop Client launches properly.



## Updating Software via DealerCONNECT

Updates to your StarMOBILE software are also available via DealerCONNECT. Your StarMOBILE Desktop Client will automatically alert you that software is available when you login to DealerCONNECT.

You can also check for updates from by selecting *File > Update Software* from your StarMOBILE Desktop Client application.



## Updating the StarMOBILE Device OS

Your StarMOBILE Desktop Client will automatically upgrade your StarMOBILE device (if an update is required) when it connects to your StarMOBILE device. You may also choose to upgrade your StarMOBILE device manually using the *StarSCAN & StarMOBILE Update CD*.

### Updating automatically using the *StarMOBILE Desktop Client*

Follow the steps below to upgrade your StarMOBILE device OS automatically using the StarMOBILE Desktop Client.

#### *Step 1: Launch the StarMOBILE Desktop Client*

Click on the StarMOBILE Desktop Client icon on your PC's desktop to launch the StarMOBILE Desktop Client.




#### *Step 2: Follow the StarMOBILE Discovery Wizard*

Follow the steps in the StarMOBILE Discovery Wizard to connect to your StarMOBILE device.



## *Step 3: Follow the StarMOBILE Update Wizard*

If your StarMOBILE device requires an upgrade, the StarMOBILE Desktop Client will automatically launch the StarMOBILE Update Wizard. Follow the steps of this wizard to automatically upgrade the software in your StarMOBILE device.



## *Update manually using the StarSCAN & StarMOBILE Update CD*

Insert the *StarSCAN & StarMOBILE Update CD* and choose *Download Software Updates*. This will launch a wizard that will guide you through the steps required to manually update your StarMOBILE device.

